

Atari 2600 Junior – PAL

1. Remove all components shown in **RED**.
2. Connect the points marked in **BLUE** (5V, GND, VID-IN, AUD-IN) **ONLY!**
3. Use double sided tape to mount the Composite Mod board where the RF box used to be.

Connect the AUD-OUT and VID-OUT to corresponding RCA Phono sockets mounted on the rear of the console and find a suitable ground point for those as well.

