

# Atari 2600 Junior – PAL

1. Remove all components shown in **RED**.
2. Cut all traces marked in **PURPLE**.
3. Lift or cut all pins marked in **YELLOW** (\*See Below)
4. Connect all the points marked in **BLUE** to the corresponding pads on the Atari 2600 MultiMod Board.
5. Use double sided tape to mount the MultiMod board where the RF box used to be.

\* You can either use a separate toggle switch to pause the game by connecting a switch between SW1 and SW2 or you can just connect SW1 to the point shown and lift the pin marked in **YELLOW** above and it can be controlled using the B&W switch on the lid of the console.

As this is a PAL console, you will only use 1 audio channel, so it will be only necessary to use AUD-IN1 and AUD-OUT1.

Connect the AUD-OUT1 and VID-OUT to corresponding RCA Phono sockets mounted on the rear of the console and find a suitable ground point for those as well.

